

Figure: 30 TAC §115.465(2)(B)(i)

$$CE = \frac{GW}{(GW + FW)}$$

Where:

CE = The capture efficiency, decimal fraction.

G_W = The mass of volatile organic compounds (VOC) captured and delivered to control device using a temporary total enclosure (TTE) (use Procedure G.2).

F_W = The mass of fugitive VOC that escapes from a TTE (use Procedure F.1).