

Figure: 30 TAC §115.475(3)(B)(ii)

$$CE = \frac{(L-F)}{L}$$

Where:

CE = Capture efficiency, decimal fraction.

L = The mass of liquid volatile organic compounds (VOC) input to process (use Procedure L).

F = The mass of fugitive VOC that escapes from a temporary total enclosure (use Procedure F.1).