

Figure: 30 TAC §115.475(3)(B)(iii)

$$CE = \frac{G}{(G + F_B)}$$

Where:

CE = Capture efficiency, decimal fraction.

G = The mass of volatile organic compounds (VOC) captured and delivered to a control device (use Procedure G.2).

F_B = The mass of fugitive VOC that escapes from the building or room enclosure (use Procedure F.2).